

## Assembly Instructions



(W x D x H) m1.83 x m0.54 x m2.77

Product Name: Rustic Arch

Pressure Treated products should not be treated with any other products for the first month.

**PLEASE KEEP THESE INSTRUCTIONS**

Zest4Leisure

01352 752555 option 1 – sales@zest4leisure.co.uk

# Rustic Arch Assembly Instructions

Requires 2 person assembly.

Tools required: Corded / Cordless Drill, Pozi-drive Bit / Screwdriver, 13mm Spanner. , 3mm Drill Bit required in order for you to drill all screw holes before construction.

Rustic Arch Pack List		
Item	Description	Quantity
A	Roof Panel	2
B	Side Panel	2
C	Diagonal Bracings	4

Fixings		
	Bolt, Nut & Washer	2
	100mm Screw	8



Please take a few moments to check all pack contents listed.


Assembly requires 2 persons.

**Tools required: Corded/Cordless Drill, Pozi-drive Bit/Screwdriver, 13mm Spanner, 3mm Drill Bit required in order for you to drill all screw holes before construction.**


1. Align Roof Panels A to form an apex (Fig.1a) and attach using 2no M8 Bolts, Nuts and Washers (Fig.1b).
2. Position Side Panel B as shown in Fig.2.
3. Connect Side Panel B to Roof Panel A using 2no Diagonal Bracings C (Fig.3) using 4no 100mm Screws – 2no per bracing.

Repeat stages 2 & 3 for remaining Side Panel B and Bracings C.


1a



1b



2



3



Rustic Arch is now complete.