



Assembly Instructions



(W x D x H) 2.22m x 1.80m x 2.14m
Product Name: Hollywood Swing

Pressure Treated products should not be treated with any other products for the first month.

PLEASE KEEP THIS INSTRUCTION

Zest4Leisure
01352 752555 option 1 – sales@zest4leisure.co.uk


Hollywood Swing Assembly Instructions

Requires 2 person assembly.

Tools required: Corded / Cordless Drill, Pozi-drive Bit / Screwdriver, Socket Set, Hammer, 3mm Drill Bit required in order for you to drill all screw holes before construction.

Hollywood Swing Pack List		
Item	Description	Quantity
A	Leg	4
B	Beam	1
C	Horizontal Short Brace	2
D	Horizontal Long Brace	2
E	Diagonal Brace	2
F	Seat Back	1
G	Seat	1
H	Armrest Support	2
J	Armrest	2
K	Shelf (Optional Extra)	2
L	Beam Capping	1

Fixings		
	60mm Screws	8
	45mm Bolts, washers & nuts	6
	100mm Bolts, washers & nuts	22
	115mm Eye Bolts & small karabiner, washers & nuts	4
	150mm Bolts, washers & nuts	2
	150mm Eye Bolts & large karabiner, washers & nuts	2
	990mm Chain	2
	1140mm Chain	2



Please take a few moments to check all pack contents listed.


Assembly requires 2 persons.

Tools required: Corded/Cordless Drill, Pozi-drive Bit/Screwdriver, Socket Set, Hammer, 3mm Drill Bit required in order for you to drill all screw holes before construction.


1. Position 2no Legs A either side of Beam B (Fig.1a), align bolt holes and attach using 1no 150mm Bolt, washer & nut (Fig.1b). Do not fully tighten at this stage. Repeat procedure for the remaining 2no Legs A at the other end of Beam B.
2. Position Horizontal Short Brace C (Fig.2a) and Horizontal Long Brace D (Fig.2b) onto Legs A, align bolt holes and insert 8no 100mm Bolts – 4no per horizontal brace. Repeat procedure for the remaining braces and Legs A.
3. Turn over the Legs/Beam Assembly (Fig.3a), attach washers and nuts and fully tighten (Fig.3b).
4. Attach Diagonal Brace E to Beam B using 2no 100mm Bolts, washers & nuts and fully tighten (Fig.4a). Raise Leg Assembly, align Diagonal Brace E & Horizontal Short Brace C bolt holes and fix in position using 1no 100mm Bolt, washer & nut (Fig.4b). Fully tighten all nuts at this stage. Repeat procedure with the remaining Diagonal Brace E at the other end of Beam B (Fig.4c).
5. Insert 2no 150mm Eye Bolts into the Beam B (Fig.5) and secure using washers and nuts.
6. Locate half lap joints of Seat Back F into half lap joints of Seat G and fix in position using 6no 45mm Bolts, washers & nuts – 2no per joint (Fig.6b)
7. Locate the Armrest Support H dowels into the Armrest J holes (Fig.7a) and fix in position using 1no 60mm Screw (Fig.7b). Repeat procedure for the remaining Armrest Support H and Armrest J.
8. Attach Armrest Assembly to Seat Assembly using 2no 115mm Eye Bolts as shown in Figs 8a & 8b. Repeat procedure for the remaining Arm Assembly.
9. Hook 1no Short Chain & 1no Long Chain onto Large Karabiner ensuring Short Chain is at the back (Fig.9a). Repeat procedure for remaining chains. Attach Short Chain to the back of the Seat Assembly (Fig.9b) and Long Chain to the front of the Seat Assembly (Fig.9c) using 2no Small Karabiners. Repeat procedure for remaining Chains.
10. Locate Shelves K (**Optional Extra**) onto Long Braces D (Fig.10).
11. Position Beam Capping L centrally along Beam B (Fig.11a) and fix in position using 6no 60mm Screws – 1no into each Leg A (Fig.11b) and 2no into Beam B (Fig.11c)

Hollywood Swing is now complete.


1a




1b




2a



2b




3a




3b




4a



4b



4c



5




6a



6b



7a



7b



8a




8b




9a



9b




9c




10



11a



11b



11b

